

Instruction Sheet

912144

717VG-0994

This instruction sheet is to be used with:

REPAIR PART NO.: 902115

DESCRIPTION: BELT WITH SILICONE GREASE

The dishwasher belt must be lubricated with silicone grease once the belt is installed.

TO INSTALL: Place belt in motor pulley groove and stretch belt with your left hand until you are able to place the belt into the back side of the power module pulley groove. While holding the belt in place, turn the pulley counter-clockwise until the belt is installed.

TO LUBRICATE: Twist cap off the tube of silicone grease and apply an ample amount along the entire circumference of the belt.

FICHE D'INSTRUCTIONS

Cette fiche d'instructions doit être utilisée avec:

NO DE PIECE DE RECHANGE: 902115

DESCRIPTION: COURROIE AVEC GRAISSE DE SILICONE

Une fois la courroie du lave-vaisselle montée, elle doit être lubrifiée à la graisse de silicone.

MONTAGE: Placer la courroie dans la rainure de la poulie du moteur et, avec la main gauche, tirer sur la courroie jusqu'à ce qu'elle puisse se placer dans la rainure derrière la poulie du bloc de puissance. Tout en tenant en place la courroie, tourner la poulie dans le sens anti-horaire pour monter la courroie.

LUBRIFICATION; Enlever en le tournant le capuchon du tube de graisse de silicone et mettre une bonne quantité de graisse tout autour de la circonférence de la courroie.