

INDUSTRIAL / INSTITUTIONAL APPLICATIONS & DILUTIONS CHART

DILUTIONS KEY:		
\overline{L} - LIGHT [up to 150 parts water]		
${f M}$ - <code>MEDIUM</code> [30 to 100 pts. water]	SIMPLE	CRYSTAL
f H - HEAVY [1:1 up to 20 pts. water]	GREEN®	SIMPLE
APPLICATIONS:		GREEN®
Aluminum	H	H-M
Automotive - exteriors	M	M
Buses/Vans	M	M-L
Car Wash - Automated	M	M-L
Carbon deposits	H	H
Carpets: General *1	M	M-L
Spot cleaning *2	Н	H-M
Chrome	M	M-L
Computers: Cases	M	M
Screens	L	L
Concrete	Н	Н
Decks: Metal	H	H-M
Wooden	H	H-M
Diesel fuel	H	Н
Dip tanks & Parts Washers	Н	Н
Engine degreasing	Н	H-M
Fiberglass	Н	H-M
Floor scrubbers	M	M
Floors: Concrete	Н	H-M
No-Wax	M	M
Stripping Wax*3	H	Н
Garbage receptacles	H	Н
General cleaning	M	M-L
Glass & Mirrors	L	L
Grease filters & traps	H	H-M
Grout	Н	H- M

APPLICATIONS:	SIMPLE GREEN®	CRYSTAL SIMPLE GREEN®
Kitchens: counters, walls, floors, appliances	Н	H-M
Laundry: Full load *4	Н	Н
Spot cleaning *1	Н	Н
Pre-wash/soak	Н	H-M
Lights	L	L
Lubricants - machinery grease, oils	Н	H-M
Machinery	Н	H-M
Manufacturing Equipment	Н	H-M
Motors	Н	H-M
Oil deposits	Н	H- M
Paint preparation	Н	H-M
Pressure sprayers	M	M -L
Showers, Tubs & Tile	Н	H-M
Smoke & soot	Н	H-M
Sports equipment	M	M-L
Toilets	M	M-L
Tumblers	Н	H-M
Upholstery *1	M	M-L
Vents	H	H-M
Windows	L	L

APPLICATION NOTES:

- * 1 Always spot test for colorfastness in an inconspicuous area first.
- * 2 Spot test as above. Dampen area to be cleaned with clean water. Apply Simple Green or Crystal Simple Green and let sit for 1 to 2 minutes. Agitate if necessary but don't "scrub". Wipe up with clean cloth and water
- * 3 Wet floor with hot water. Apply Simple Green or Crystal Simple Green. Let stand for several minutes and then rinse with hot water.
- * 4 Pour 1/4 cup of full strength Simple Green or Crystal Simple green into a full load of laundry and reduce normal detergent by 1/2.

ALWAYS READ PRODUCT LABELS BEFORE USE. QUESTIONS SHOULD BE DIRECTED TO:

SIMPLE GREEN INDUSTRIAL CUSTOMER SERVICE - (800) 228-0709.