

INSTALLING THE HEAVY DUTY DRYER HOOK UP KIT:

- ❶ Thread the Dryer to Duct Connector into the Semi Rigid-Duct.
- ❷ Thread the Duct to Exhaust Hood Connector to the other side of the Semi Rigid Duct ensuring that it faces the opposite direction as the Dryer to Duct Connector.
- ❸ (A) Push the Dryer to Duct Connector onto the dryer exhaust outlet. This connector is secured to the dryer via pressure fit and does not require clamping.
(B) **NOTE:** Some dryers have a recessed exhaust outlet. If so, connect the Dryer Exhaust Extension Piece to the Dryer to Duct Connector before connecting to the dryer.
- ❹ Stretch the Semi Rigid Duct to the required length to reach the existing duct work leading to the outdoors.
- ❺ Insert the Duct to Exhaust Hood Connector into the existing duct work.
- ❻ Secure the connector to the existing duct work using the 4" metal clamp provided in this kit.
- ❼ Push the dryer back into place.

