




WALL SLEEVE INSTALLATION INSTRUCTIONS

FOR PAWS1 PERFECT AIRE THRU-THE-WALL AIR CONDITIONER WALL SLEEVE


SLEEVE HARDWARE

The following pieces are included with your Perfect Aire wall sleeve:


ITEM	DESCRIPTION	QTY.
1	Top Panel	1
2	Right Side Panel	1
3	Left Side Panel	1
4	Bottom Panel	1
5	Brackets	4
6	Sleeve Clasps	4
7	Screws ST3.9*10	28
8	Washers	8
9	Rear Cover Panel	1
10	Front Cover Panel	1



SLEEVE DIMENSIONS




SLEEVE INSTALLATION




ASSEMBLY & INSTALLATION

STEP 1: ASSEMBLE THE WALL SLEEVE


- Use four screws to fasten the side panels to the bottom panel as shown below. NOTE: The arrows on the bottom panel indicate the inside of the sleeve.



- Place the top panel on the top and fasten with four screws as shown below.





- Insert the four sleeve clasps into the quadrate holes in the side panels as shown below.



**▶ STEP 1: (CONTINUED)
ASSEMBLE THE WALL SLEEVE**

- Insert the louvered rear grille or the expanded rear grille (packed with air conditioner you purchased) and fasten with 4 washer screws as shown below.



- Install two brackets on top and one bracket on each side of the sleeve; fasten with four screws. There are two methods to install the brackets, as shown below in FIG. A and FIG. B.

NOTE: Choose any one hole on the bracket to fasten the screws on the sleeve, according to your application.





FIG. A


FIG. B

NOTE: To improve the firmness of the sleeve, it is recommended to install 8 more screws, as shown below.



**▶ STEP 2:
INSTALL THE UNIT**

- Before installing the unit, remove the old air conditioner from the existing wall sleeve and remove the existing wall sleeve.
- Prepare and install the new wall sleeve into the wall opening.
- Put the assembled sleeve into a wall opening as shown below, then place the air conditioner into the sleeve.



- The wall sleeve must be securely fastened to the wall before installing the new air conditioner.
- Keep the cover panels for later use to protect the sleeve from rainy or windy weather.
- To avoid distortion to the front panel of the air conditioner, the sleeve should be installed at a distance of 4 inches minimum from heating source (e.g. baseboard heating, radiator, etc.).
- After sleeve has been installed, caulk the entire perimeter around exterior wall opening and sleeve. Use a good grade of caulk to seal all cracks against air and water infiltration.
- The rear grille, washer and screws should be kept in a safe place until the air conditioner is installed.

**▶ STEP 3:
INSTALL THE COVER PANELS
(WHEN NOT USING AIR CONDITIONER FOR A LONG TIME)**

- To install cover panel at the back of sleeve, first remove air conditioner from sleeve.
- Take the louvered rear grille or the expanded rear grille out by loosening the four washer screws, as shown in FIG. C.




FIG. C

- From the inside of the sleeve, insert the rear cover panel and re-insert the four washer screws through the panel, as shown in FIG. D and FIG. E. Tighten the screws.




FIG. D




FIG. E

- Use the front panel to cover the front of the sleeve and fasten with 4 screws, as shown in FIG. F.




FIG. F

Distributed by:



Perfect Aire, LLC
5151 Belt Line Rd.
Suite 878
Dallas, TX 75254

844-4PA-AIRE | 844-472-2473
www.perfectaire.us

Specification and performance data is subject to change without notice.

Printed in China