






PARTS TABLE ON PAGE 42

ITEM #	PART #	DESCRIPTION
1	060386A	Rigid/Swivel Spout Adaptor and Fibre Gasket – 1 of each
2	060148A	Red and Blue Index Kit – 12 of each
3	77189	2-3/4" Hooded Lever Blade Handle, Screw, Red & Blue Index – 1 of each
4	77130	Spout with No Brace Bracket or Integral Vacuum Breaker (3.2" centers) (For Additional Spouts with No Brace Bracket or Integral Vacuum Breaker, See Page 37)
5	77393	Spout with Top Brace Bracket and No Integral Vacuum Breaker (5.5" centers) (For Additional Spouts with Top Brace Bracket and No Integral Vacuum Breaker, See Page 37)
6	060373A	Spout Nut
7	060245A	Retaining Ring Kit – 6 per
8	060244A	Rigid Collar Kit (Brass) – 6 per
9	77260	RH Structure & Renewable Seat (opens to the right – see text under each handle for HOT/COLD side requirements)
	77261	LH Structure & Renewable Seat (opens to the left – see text under each handle for HOT/COLD side requirements)
10	060144A	Renewable Seat Kit – 12 per
11	060143A	Spout "O" Ring Kit – 24 per
12	060470A	Nipple Kit – 2 per
13	060466A	Wall Flange and Set Screw Kit – 2 of each
14	060387A	Set Screw Kit – 10 per
15	060388A	Standard Shanks and Rubber Washers – 2 of each
16	060465A	Rubber Washer Kit – 12 per
17	060471A	Offset Shanks and Rubber Washers – 2 of each
18	060440A	Drive Bit – No. 3 Square
19	060469A	Fibre Washer Kit – 12 per
20	28T911	48" Hose and Stainless Steel Hanger
21	76094-1	Top Wall Brace assembly
22	060140A	Stem "O" Ring Kit – 24 per
23	060142A	Structure "O" Ring Kit – 24 per
24	060139A	Seat Washer Kit – 24 per
25	060243A	Screw – 6 per
26	060021A	Bulk Structure Repair Kit – 12 Seat washers (#24), 2 Screws (#25), 24 Stem "O" Rings (#22), 6 Structure "O" Rings (#23), 4 Seats (#10), 18 Structure Fibre Washers (Not Shown)
27	060257A	Garden Hose End Adapter
28	060145A	11/16" Long Handle Screws – 12 per
29	76066	Garden Hose End Vacuum Breaker
30	060472A	Check Structure, Gasket and Cap – 2 of each
31	060389A	Check Structure Repair Kit – "O" Rings and Spring – 6 of each
32	060272A	Spout with Top Brace Bracket and Integral Angle Vacuum Breaker (5.75" Centers) (For Additional Spouts with Top Brace Bracket and Integral Angle Vacuum Breaker, See Page 37)



ITEM #	PART #	DESCRIPTION
33	060390A	Gasket Kit – 6 per
34	060391A	Check Structure Cap Kit – 2 per
35	060026A	Spout Repair Kit – 1 Rigid Brass Collar (#8), 6 Retaining Rings (#7), 12 Spout "O" Rings (#11), 1 Spout Nut (#6)
36	060393A	Wall Flange Screw Kit – 12 per
37	060474A	Wall Flange
38	060147A	Screws – 24 per
39	060392A	Wall Bracket Yoke
40	060271A	Spout with Integral Angle Vacuum Breaker and No Brace Bracket (For Additional Spouts with Integral Angle Vacuum Breaker and No Brace Bracket, See Page 37)
41	500066A	Hose End Vacuum Breaker Repair Kit
42	*	Contact Watts Regulator for Repair Kit for Model # 288A-C (1/2")
43	060473A	Optional Thin Wall Trim – Shank, Steel Washer, Nut & Elbow – 2 of each



PARTS TABLE ON PAGE 38

MAIN BODY PARTS

See Page 35

ITEM #	PART #	DESCRIPTION
1	77131	Spout with No Brace Bracket or Integral Vacuum Breaker – (X=8")
	77130	Spout with No Brace Bracket or Integral Vacuum Breaker – (X=3.2")
2	060449A	Spout with No Brace Bracket but with an Integral Inline Vacuum Breaker – (X=8")
	060297A	Spout with No Brace Bracket but with an Integral Inline Vacuum Breaker – (X=4.25")
3	77135-0	Spout with No Brace Bracket but with an Integral Angle Vacuum Breaker – (X=8")
	060271A	Spout with No Brace Bracket but with an Integral Angle Vacuum Breaker – (X=3.5")
4	060317A	Spout with Top Brace Bracket and No Integral Vacuum Breaker – (X=8")
5	77454-0	Spout with Top Brace Bracket and Integral Inline Vacuum Breaker – (X=8")
6	060373A	Spout Nut
7	060245A	Retaining Ring Kit – 6 per
8	060244A	Rigid Collar Kit (Brass) – 6 per
9	77136	Spout with Top Brace Bracket and Integral Angle Vacuum Breaker – (X=8")
10	77133	Spout with Bottom Brace Bracket and No Integral Vacuum Breaker – (X=8")
11	060143A	Spout "O" Ring Kit – 24 per
12	77144	Female Moderator and Wrench (#16)
13	77142	Female Aerator – (Not Vandal Resistant)
14	77158	Female Aerator and Wrench (#16)
15	77455-0	Spout with Bottom Brace Bracket and Integral Inline Vacuum Breaker – (X=8")
16	17195	Wrench for Vandal Resistant Outlets
17	77137-0	Spout with Bottom Brace Bracket and Integral Angle Vacuum Breaker – (X=8")
18	060257A	Garden Hose End Adaptor
19	76066	Garden Hose End Vacuum Breaker
20	28T911	48" Hose and Stainless Steel Hanger
21	76094-1	Top or Bottom Wall Brace Assembly
22	76093	Bottom Fork Wall Brace Assembly
23	060392A	Wall Bracket Yoke
24	060147A	Screws – 24 per
25	060393A	Wall Flange Screw Kit – 12 per
26	060474A	Wall Flange
27	060026A	Spout Repair Kit – 1 Rigid Brass Collar (#8), 6 Retaining Rings (#7), 6 Swivel Plastic Collars (#Not Shown), 12 Spout "O" Rings (#11), 1 Spout Nut (#6)
28	500066A	Hose end Vacuum Breaker Repair Kit
29	*	Contact Watts Regulator for Repair Kit for Vacuum Breaker # N9C (3/8")
30	*	Contact Watts Regulator for Repair Kit for Vacuum Breaker # 288A-C (1/2")

