


# Instruction Sheet

16023592

## Description: Light Switch Kit

Repair Part Number: 12002646

Kit includes:




### WARNING


To avoid risk of electrical shock, personal injury or death; disconnect electrical power before servicing.

**Note:** This procedure is only required when harness connector does not match light switch.

1. Disconnect electrical power to unit before removing light switch.
2. Remove existing light switch by prying switch out with a taped putty knife.




3. Disconnect switch from harness connector.
4. Cut harness connector between purple with white stripe and red with white stripe. (See photo page 2)



Cut harness connector between purple with white stripe and red with white stripe.

5. Plug in two wire half of connector in normally as installed on original switch. Rotate red with white stripe wire 180 degrees and plug into new light switch. This will give more clearance to plug in connector.



Rotate red with white stripe wire 180 degrees and plug into new light switch

6. Reinstall new light switch and reconnect electrical power to unit, then test for correct light switch operation.