

P451 Series Delany Flush Valve, Exposed for Urinal

Part No Description

23-5A	Stopper Disc
44-4	Stop Bonnet
44-4A-J	Stop Bonnet Assembly
49	Shut off Stem Packing
52-4	Shut off Stem
57	Clamping Nut
58	Union Nut
60	Bonnet Washer
62	Back Check Spring
64	Tailpiece
65	O-Ring
66	Clamping Ring
69	Stop Cap
73NS	Packing Nut
195K	Flange, Tube, & Solder Adaptor Kit
302-1	Spud Flange
375A	Spud Nut with Rubber Washer
376	Rubber Washer
426	Cowl Nut
427A	Vacuum Breaker Sleeve
428B-9	Flush Tube, 9" Long
P2	Cover Screw Washer
P3	Cover Screw
P4	Regulating Screw
P8 **	Auxiliary Valve Seat
P16	Diaphragm Bushing
P28G **	Packing
P102-P1A	Valve Seat & Washer
P103U	Seat Guide
P104	Auxiliary Seat Holder
P107-1U **	Diaphragm with Bypass
P107-1AU	Complete Diaphragm Kit
P109A	Cover Assembly
P114	Auxiliary Valve
P222-3 **	Rubber Handle Flexer
P223-2	Operating Stem (1-11/16")
P333A	Handle Assembly

Parts Not Shown

** 039003	Soft Parts Kit
187A-J	Complete Stop Assembly, 3/4" NPT

