

Instruction Sheet for Heater Element kit

Kit Contains:

- 1 Heater Element
- 2 Heater Fasteners
- 1 Instruction Sheet

NOTE: These instructions only apply to the heater and heater fasteners in this kit.

! WARNING



Electrical Shock Hazard

Disconnect power before servicing.
Replace all parts and panels before
operating.

Failure to do so can result in death
or electrical shock.

1. Unplug dishwasher or disconnect power.
2. Replace heater.

IMPORTANT: Hand tighten the heater fasteners and then with a wrench or socket, turn fasteners 1/2 turn to secure heater element to tub. See *Figure 1*.

Do not over tighten - it can create a leak. After installation is complete, run the dishwasher and check for leaks.

© Whirlpool Corporation 2014
(All Rights Reserved)




FIGURE 1