

INSTRUCTION SHEET

for 4387911 Switch




⚠ WARNING

Electrical Shock Hazard

Disconnect power before servicing.
Replace all panels before operating.
Failure to do so can result in death or electrical shock.

The switch you have received may or may not be identical to the switch being replaced.



TO REPLACE 2-TERMINAL NORMALLY OPEN SWITCH WITH A 3-TERMINAL SWITCH:

Wire only the "common" terminal and the "normally open" terminal.

TO REPLACE 2-TERMINAL NORMALLY CLOSED SWITCH WITH A 3-TERMINAL SWITCH:

Wire only the "common" terminal and the "normally closed" terminal.

TO REPLACE 3-TERMINAL SWITCH:

Hookup on the replacement is the same as on the original.

FEUILLE D'INSTRUCTIONS

Interrupteur 4387911



! AVERTISSEMENT


Risque de choc électrique

Déconnecter la source de courant électrique avant l'entretien.

Replacer tous les panneaux avant de faire la remise en marche.

Le non-respect de ces instructions peut causer un décès ou un choc électrique.

L'interrupteur reçu peut ou peut ne pas être identique à l'interrupteur que l'on remplace.



POUR REMPLACER UN INTERRUPTEUR NORMALEMENT OUVERT À 2 BORNES PAR UN INTERRUPTEUR À 3 BORNES:

Ne câbler que la borne «neutre» et la borne «normalement ouverte».

POUR REMPLACER UN INTERRUPTEUR NORMALEMENT FERMÉ À 2 BORNES PAR UN INTERRUPTEUR À 3 BORNES :

Ne câbler que la borne «neutre» et la borne «normalement fermée».

POUR REMPLACER UN INTERRUPTEUR À 3 BORNES :

Brancher l'interrupteur de rechange de la même manière que l'interrupteur d'origine était branché.