


PUSH-FIT supply valves connect to copper, CPVC & PEX tubing without tools or soldering

Universal design, for most types of faucets

INCLUDED IN THIS KIT:

- Two angle PUSH-FIT supply valves
- PUSH-FIT removal tool
- Two chrome plated stainless steel escutcheon plates
- Two extra long 20" braided stainless steel faucet connectors



Les robinets d'alimentation POUSSER-RACCORDER se raccordent sur des tuyauteries en cuivre, PVCC et PEX sans outils, sans brasure


Conception universelle pour la plupart des types de robinets

COMPRIS DANS CETTE TROUSSE:

- Deux robinets d'alimentation du type POUSSER-RACCORDER équerres
- Outil de démontage POUSSER-RACCORDER
- Deux plaques cache-entrée en acier inoxydable chromé
- Deux raccords flexibles pour robinet en acier inoxydable tressé extra-long de 20 po


PUSH-FIT VALVE INSTALLATION INSTRUCTIONS

DIRECTIVES D'INSTALLATION POUR ROBINETS POUSSER-RACCORDER



CUT TUBING AND
REMOVE BURRS

COUPER LE TUYAU ET
ÔTER LES BAVURES



MARK AT:
MARQUER À:
15/16"

FOR - POUR PEX:


TUBE LINER IS
INCLUDED IN VALVE

LA CHEMISE POUR
TUYAU EST INCLUS
DANS LE ROBINET

DETAILED INSTALLATION
INSTRUCTIONS AT:


MODE D'INSTALLATION
DÉTAILLÉE:

www.johnlschultz.com



INSERT FIRMLY UNTIL IT
STOPS AND TWIST.

INSÉRER FERMEMENT
JUSQU'À CE QU'IL
S'ARRÊTE ET TOURNER



UTILISEZ L'OUTIL DE
DÉMONTAGE POUR
ENLEVER LE ROBINET