

INSTALLATION INSTRUCTIONS


The enclosed part will probably be longer than your original. If this is true, use your old part to mark the correct length on the new part, and then cut off the unneeded portion. Parts shall be free of sharp edges on the inside and outside.

Instruction Sheet 978722 Rev. C 2/88


INSTALL ICE MAKER

The instructions on this sheet replace the step called "INSTALL ICE MAKER" (step 8 or 9 depending on the model) in your manual.


1. Align the mounting clips with the holes in the liner wall and attach them with 2 screws. Tighten the screws.



2. Connect the ice maker plug to the wiring harness. The green wire must be at the top.



3. Push the ice maker tabs under the mounting clips. Push the ice maker up until tabs snap into place.



4. Attach the ice maker bottom bracket to the liner wall with a sheet-metal screw. Tighten the screw.

5. Level ice maker:

- Loosen the leveling screw.
- Adjust the ice maker.
- Tighten the leveling screw.

