1 Electrolux

ELECTROLUX HOME PRODUCTS NORTH AMERICA

INSTRUCTIONS FOR KIT 5303918375 TO INSTALL HINGE SHIM KIT.


Kit Contents:


- (4) 240311303 Round shim spacer
- (1) 240578902 additional support bolt

Note: Remove all items from the shelving of the fresh food and freezer door.


- 1. Remove freezer hinge bolts and hinge and remove freezer door from cabinet.
- 2. Remove center hinge pin and remove lower door from cabinet.
- 3. Remove lower hinge bolts.
- 4. Install lower hinge lower bolt and place 3 spacers on rear side of hinge on

bolt and install.





- 5. Install upper bolt on hinge left hole.
- 6. Add 3rd bolt to upper right corner of hinge for added support if needed.
- 7. It may be necessary to add spacer to lower hinge bolt.
- 8. Reinstall doors



#6 Add 3 bolt if needed for additional support



#7 If necessary, add additional nylon spacer to hinge bolt to raise door.