

Specifications

	Doorbell	Push Button
Operating Temperature	23°F to 104°F (-5°C to 40°C)	-4°F to 122°F (-20°C to 50°C)
Honeywell ActivLink™	916.8 MHz	916.8 MHz
Range (open field)	250 ft. (76 m)	250 ft. (76 m)
Sound Level (typical)	80dBA	-
RF Power	-	<1.2W
Battery Type	Input: 4 x AA (1.5 V) alkaline each	CR2032
Battery Life (5 activations/day)	Up to 2 years	Up to 2 years
Rain proof	N/A	Pass UL1598 rain test.

Troubleshooting

If	Then
The doorbell does not work	<ol style="list-style-type: none"> 1. Make sure the correct batteries (4 AA alkaline cells, 1 CR2032) are installed with the correct polarity. 2. The doorbell might be out of range; try the doorbell in a different location. 3. Reconnect the doorbell. See "Connect a Push Button".
Two 'beep' sounds are heard after the normal tune	Replace push button battery with a new CR2032.
The LED on the side turns on	Replace doorbell batteries with 4 new AA alkaline batteries.
Range is reduced	<ol style="list-style-type: none"> 1. Metal structures including uPVC door frames can reduce the range. Don't mount the the doorbell or push button on or near metal structures. 2. Move the doorbell closer to the push button. 3. Weak batteries will reduce range. In cold conditions (below 41°F [5°C]), batteries may need to be replaced more often.

For help please visit resideo.com or call 1-800-633-3991.

CAUTION: Before operating, make sure that the product components have not been damaged, have not been exposed to water or high temperatures.