

Datasheet

Operator Replacement Series


Type **RA / RAV** to **RA2000**

Selection:


Existing (OLD)
Operator Types

Replacement (NEW) Operator Types

Identifiable mounting:
Large silver threaded nut

RA Series	RA2000	Choose any of the compatible operators below:	
			015G4292
Valve mounted dial	013G8070 Required adapter (For RA valve to RA2000)	+	013G8564
013-7001 RA-6			013G8562 (6' cap. tube)
013-7101 RA-6 "Armored"			013G8565 (16' cap. tube)
			013G8568 (26' cap. tube)
RA Series	RA2000	Choose any of the compatible operators below:	
			013G8564
Remote mounted dial	013G8070 Required adapter (For RA valve to RA2000)	+	013G8562 (6' cap. tube)
013-7002 RA33			013G8565 (16' cap. tube)
013-7003 RA-36			013G8568 (26' cap. tube)
013-7004 RA-66			

Identifiable mounting:
Black or grey metal band w/ flat screw
holding the operator to the valve

RAV Series	RA2000	Choose any of the compatible operators below:	
			015G4290
Valve mounted dial/sensor	013G8072 Required adapter (For RAV valve to RA2000)		015G4240 (tamper proof)
013U8200 RAV "Built-in"			
013U1100 RAVN "Built-in"			
RAV Series	RA2000	Choose any of the compatible operators below:	
			015G4292 or 015G4042 (tamper proof)
Valve mounted dial/sensor	013G8072 Required adapter (For RAV valve to RA2000)		
013U8202 RAV "Remote"			
013U1102 RAVN "Remote"			





RAV/VMT Series		RA2000			
			+		013G8564 (6' + 6' cap. tube)
Separate remote sensor/dial		013G8593 Required adapter (For RAV/VMT valve to RA2000)			
013U2241	013U7151 RAV-33				
013U2211 (BRAVO)	013G8222				
RAV/VMT Series		RA2000		Choose any of the compatible operators below:	
			+		013G8562 (6' cap. tube)
Separate remote sensor/dial		013G8593 Required adapter (For RAV/VMT valve to RA2000)			013G8565 (16' cap. tube)
013U2241	013U7151 RAV-33				013G8568 (26' cap. tube)
013U2211 (BRAVO)	013G8222				

Ordering Information:

Code No.	Type	Description
013G8070	RA service adapter	RA valve to RA 2000 operator adapter
013G8072	RAV/VMT service adapter	RAV/VMT valve to RA 2000 operator adapter
013G8593	RAV/VMT adapter	RA2000 wall mount RAV/VMT socket adapter

Note: Consult RA2000 Datasheet or website for additional technical information.

Dimensions:



Danfoss

Tel.: 1-888-DANFOSS (326-3677) | Fax: 416-352-5981 | www.heating.danfoss.us

Danfoss can accept no responsibility for possible errors in printed materials and reserves the right to alter its products without notice. All trademarks in this material are property of the respective companies. Danfoss and Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.