

## **IMPORTANT INFORMATION**

This carton has been designed specifically for the gaskets to minimize deformity yet provide a suitable package that is acceptable for parcel post shipment. This carton also provides for convenience and ease of storage and handling.

### **PROCEDURE FOR RESTORING DEFORMED GASKETS**

If a gasket is found to be deformed after long term storage, heat the deformed sections with and electric heater, hair dryer, or a 150-300 watt light bulb. Move the source of heat back and forth over the deformed sections, establishing an even warming pattern and maintaining a distance of one (1) to four (4) inches between the gasket and heat source. Continue applying the heat in this manner until the gasket resumes its original shape.

\*\*It should be noted that this same procedure may be used to correct deformed gaskets already installed on a unit, providing that caution is exercised to prevent damage to the inner door panel.

### **IF THIS CARTON CONTAINS A MAGNETIC GASKET**

#### **Proper Handling Of Magnetic Gaskets**

Allow the gasket to reach room temperature before removing it from the carton. When carrying or handling the gasket, carry it only by gripping it at both corners to prevent breakage of the flexible magnet. **DO NOT** grip it in the middle of a rail section. **Should the magnet be found broken, it will not impair the effectiveness of the gasket.**