

TAMPER DYE (AA67) - APPLICATION INSTRUCTIONS

IT IS HIGHLY RECOMMENDED TO WEAR PLASTIC OR RUBBER GLOVES WHEN APPLYING TO AVOID CONTACT WITH SKIN.

- Tamper Dye is a gel-like substance and will stain your hands and clothes if contact is made. Therefore, only put this product directly onto a surface to determine which individual has touched the surface and to deter further tampering with surface.
- 10ml syringe covers approx. 40-50 surfaces (ie. pull station handle)
- This dye is designed to activate and spread with water. So when identifying a culprit, look for BLUE all over hands including under the fingernails and in the crevices of the hand.

APPLICATION INSTRUCTIONS:

1. Remove syringe cap carefully.
2. Squeeze only a very small amount of gel directly onto the surface (ie. on inside rim of pull station handle).
3. Reapply the Tamper Dye only after the surface has been touched.

AVOID CONTACT WITH EYES AND MOUTH. SEE MSDS DATA SHEET FOR MORE INFORMATION AT WWW.SAFETYMEDIA.COM

Questions?

Safety Media Inc.

(800) 420-9737 or www.safetymedia.com