

RETROLINE® Retrostat Cover Kits

Product Description

The Retrostat Cover kits provide an adaptable cover for use with the TH 19X thermostat.

Contents

Part	Quantity
Retrostat Cover	1
Bezel	1
Dial Plates	6
Thumb Wheel Hole Cover	2

Product Numbers

Retrostat Kit	Type
192-868	Desert Beige Cover
192-868W	White Cover

Prerequisites

- Review all of these instructions before you begin installation.
- Check job drawings for any site-specific information.

Expected Installation Time

5 minutes

Required Tools

- Needle nose pliers

Installation Conventions

WARNING		Personal injury/loss of life may occur if a procedure is not performed as specified.
CAUTION		Equipment damage, or loss of data may occur if the user does not follow procedure as specified.

Installation

See *Figures 1* and *2*.

1. Determine which dial plate is needed and place it in the recessed area on the front of the cover.



CAUTION:

Always make certain you select the proper dial plate before installing the bezel. The bezel is difficult to remove once it is in place on the retrostat cover.

2. Place the bezel over the dial plate and snap it into place.
3. Use the thumb wheel hole covers to hide any unused openings or to conceal any thumb wheels.
4. For day/night thermostats use a needle nose pliers to carefully remove the plastic cover from the day/night selector handle slot. Discard this cover.
5. Install the cover assembly to the device on the wall.

The installation is complete.




Figure 1. Adapting the Cover.




Figure 2. Dial Plates.

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. Product or company names mentioned herein may be the trademarks of their respective owners. © 2009 Siemens Industry, Inc.