Milwaukee **BULLETIN NO. SERVICE PARTS LIST** 54-49-2710 REVISED BULLETIN SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS DATE Sept. 2016 M18™ FUEL™ STRING TRIMMER wiring instruction See Page 2 STARTING SERIAL NO CATALOG NO. 2725-20 **H35A** Milwoodse 62c Rubber Pads with adhesive (84) are to be placed in both Housing Halves (2 and 12). 62d **13** 9x 15 2x 62 62a 62b 62c 62d 62e **16** 1x 11 (6x) 12 63 1 14 20 (2x) 13 (9x) 65 3 (2x) 64 2 12 68 21 22 29 25 $71\frac{28}{30}\frac{29}{67}$

FIG.	PART NO.		D. REQ.
1		Lower Cover Halve-Left	1
2		Housing Support-Left Housing Halve	1
3		Motor Insulator-Left	1
10		Motor Insulator-Right	1
11	06-82-1080	M3 x 14mm Pan Hd. ST T-10 Screw	6
12		Housing Cover-Right Housing Halve	1
13	05-88-1200	M4 x 16mm Pan Hd. ST T-20 Screw	9
14		Lower Cover Halve-Right	1
15	05-88-1300	M4 x 28mm Pan Hd. ST T-20 Screw	2
16	05-88-5375	M4 x 13.5 Pan Hd. ST T-20 Screw	1
19	42-68-0292	Carrier Handle Clip	2
20	05-55-0006	M6 Hex Nut	2
21	02-04-0034	Ball Bearing	1
22		Rotor with Drive Shaft Coupling	1
24	06-82-7240	6-19 x 1/2" Pan Hd. ST T-15 Screw	4
25	45-72-0083	On-Off Trigger	1
26	45-72-0084	Release Trigger	1
28	05-74-0013	M4 x 20mm Hex Skt. Hd. Cap Screw (Silver) 1
29	44-34-0095	Motor Mount Assembly with Bearing	[^] 1
30	05-55-0004	M4 Hex Nut (Silver)	1
31	40-50-0373	Spring	1
32	05-74-0015	M6 x 21.5mm, 5mm Hex Socket Cap Screw	4
33		Carrier Handle	1
41	05-81-0131	M6 x 18mm, 5mm Hex Flat Hd, Screw	1
42	05-85-0080	M8 x 1.25 Hex Hd. Screw	1
43		String Guard	1
44	42-26-0024	Line Cut-Off Blade	1
45	05-74-0935	M5 x 15mm Pan Hd. T-25 Machine Screw	2
46	05-81-0132	M6 x 14mm Pan Hd. T-30 Machine Screw	4
52	44-66-0029	Lock Plate Assembly	1
53		Trimmer Head Body	1
54		Trimmer Head Spring	1
55		Spool and Bump Knob	1
56		0.080" x 150' String	1
57		Trimmer Head Cover	1
58		Guideline Eyelets	2
59	14-30-0205	Gearcase Assembly	1
60	14-32-0140	String Guard Assembly	1
61	14-34-0124	Carrier Handle Assembly	i
62	14-20-0056	Electronics Assembly	i
62a		On-Off Switch	i
62b		Two Speed Selector/PCBA Assembly	i
62c		Battery Connector/PCBA Assembly	1
62d		Hall Board Assembly	1
62e		Stator Assembly	1
63	31-44-0181	Lower Cover Kit	1
64	31-44-0182	Housing Kit	1
J-1	0. 44 0102	riodonig rat	

16 (1x)

04 84 00 00 00 00 00 00 00 00 00 00 00 00 00	
60 43 44 45 46 42 59 42	
42 Hex Hd. Screw 44 46 (4x) Screw 22x) 52 81 53 54 55 53 81 56 57 58 53	
Apply grease through a squeeze tube or a manual grease gun. State of the square of th	n
It is recommended to lubricate Gearcase Assembly (59) at 50 hour intervals. Remove Hex Head Screw (42) and place 9.5-11.5g of Type 'Y' grease, 49-08-5270 inside Gearcase. DO NOT OVERFILL.)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
65	31-50-0881	Motor Insulator Kit	1
66	45-08-0174	Drive Shaft Assembly	1
67	16-01-0021	Rotor Assembly	1
68	10-20-1043	Warning Label	1
69	40-50-0374	Bias Spring	1
70	12-20-0088	Service Nameplate	1
71	14-50-2725	Rotor/Motor Mount Assembly	1
80	49-16-2711	Loaded Replacement Spool	1
81	49-16-2710	Loaded Replacement Head	1
82	49-96-0012	5mm Hex Key (Not Shown)	1
83	49-96-0055	T-30 Key (Not Shown)	1
84	44-52-0001	Rubber Pad with Adhésive (Set of 2)	1

WIRING INSTRUCTION

- · Place On-Off Switch (62a) and Two Speed Selector PCBA (62b) squarely and firmly in the cavities of the Support Housing (2).
- · Route wires from those components through the wire traps in the Support Housing, removing as much slack in the wires along the way.
- The Rotor/Stator Assemblies (62d, 62e, 67) are captured in the Motor Insulator/Motor Mount Assemblies (65, 71). Place these components squarely and firmly in the cavities of the Support Housing.
- · Route wires from those components through wire traps in the Support Housing, removing as much slack in the wires along the way.
- · Place Battery Connector/PCBA squarely and firmly in the cavity of the Support Housing.
- Be sure to tuck all wires and sleeved wire assemblies to the bottom of all wire traps.


 Carefully insert Drive Shaft Assembly (66) into the Rotor/Motor Mount Assembly (71). Be sure to orient Drive Shaft so the two holes are perpendicular to the Support Housing. Tighten Hex Screw (28) with a 3mm hex wrench to secure Drive Shaft to Motor Mount.

• Reinstall On-Off Trigger (25), Release Trigger (26) and Release Trigger Spring (31).

• Carefully place Housing Cover (12) onto Housing Support being sure to check for any interferece and secure with Screws (13).

• Attach the Lower Cover Halves (63) with Screws (15).

• Check for the proper functionality of the On-Off Trigger (25) and Release Trigger (26).



ALWAYS REMOVE BATTERY PACK BEFORE PERFORMING ANY MAINTENANCE OR REPAIRS

SCREW TORQUE SPECIFICATIONS						
			SEAT TORQUE			
FIG.	PART NO.	WHERE USED	(KG/CM)	(IN/LBS)		
11	06-82-1080	Motor Insulator	12.0-16.0	10.4-13.8		
13	05-88-1200	Housing Cover	15.0-20.0	13.0-17.3		
15	05-88-1300	Lower Cover	15.0-20.0	13.0-17.3		
16	05-88-5375	Housing Cover	15.0-20.0	13.0-17.3		
24	06-82-7240	Motor Insulator	12.0-16.0	10.4-13.8		
28	05-74-0013	Motor Mount	11.0-14.0	9.5-12.1		
32	05-74-0015	Carrier Handle	25.0-28.0	21.6-24.3		
32	05-74-0015	Gearcase Assy.	25.0-28.0	21.6-24.3		
41	05-81-0131	Gearcase Assy.	20.0-25.0	17.3-21.6		
42	05-85-0080	Gearcase Assy.				
45	05-74-0935	Line Cut-Off Blade	15.0-20.0	13.0-17.3		
46	05-81-0132	String Guard Assy.	28.0-32.0	24.3-27.7		
53		Trimmer Head	145-155	125.8-134.5		

Rubber Pads (44-52-0001) are to be placed adhesive side down in recesses of both housing halves prior to installation of motor/drive shaft assemblies.